



# Instructions KRX Rear Polycarbonate

Read through all instructions before install.

*Quick Straps – 6*

*10-24 x 5/8" Bolts (BSS) – 8*

*10-24 Lock Nuts (SS) – 8*

*Side pieces – 2*

*Small Bulb Trim – 36"*

**STEP ONE** – Remove the film and carefully place the bulb trim onto the bottom of the windshield. Take your time as the trim can be very tight.



**STEP TWO** – While standing in the bed of the KRX put one corner of the window into place and squeeze the plastic together to get the other side into place. It rests towards the back of the machine, behind the brackets, where the cage meets the plastics.

**2.1** – Place the side pieces over-lapping the main window. Then bolt the side pieces on to the back of the window with the 10-24 bolts.