



UTV  
**ZILLA™**

# Instructions KRX Full Polycarbonate

Read through all instructions before install.

*Tube Clamps 1 $\frac{3}{4}$ " – 2*

*$\frac{1}{4}$ " x 1" Bolts (BSS) – 4*

*$\frac{1}{4}$ " - 20 Lock Nuts (SS) – 4*

*$\frac{1}{4}$ " Flat Washers (BSS) – 8*

*Small Bulb Trim – 47"*



**STEP ONE** – Remove film and carefully place the bulb trim onto the bottom of the windshield. Place the windshield on the frame lining up the holes in the cage and windshield.

**STEP TWO** – Use the included tube clamp on the roll bar and bolt into place on the lower windshield holes on both sides. Now you can bolt into the KRX frame on the upper hole of the windshield.