



UTV
ZILLA™

Instructions KRX Half Polycarbonate

Read through all instructions before install.

Quick Straps – 2

Small Bulb Trim – 47"

STEP ONE – Carefully push the bulb trim onto the bottom of the windshield. Take your time it can be a very tight fit.

1.2 Install straps with the fuzzy side facing toward the center of windshield and the metal loop on the front side of the windshield.

STEP TWO – Center windshield on the machine at desired height. Wrap straps around frame and pull tight. Keep metal loop tight against windshield or strap may seem too long.

