



Half Windshield for Polaris RS1

Read through all instructions before install.

2 – Universal Billet Clamp 1.75”

2 – Bolt 1/4-20 x 2”

2 – Thumb knob with rubber washer 1/2”

1 – Bottom Bulb Seal (29”)

STEP ONE – Install rubber edge trim along bottom edge of windshield for protection during install and use. This can be difficult. Rocking the trim back and forth while applying helps it go on easier.

STEP TWO – Place clamps on the frame in approximate locations. Start the 2” bolts into the clamps but do not tighten them all the way. Allow the clamp to slide up and down on the frame.

STEP THREE – Put a rubber washer on each thumb screw before inserting through the holes in the windshield. Bolt the windshield to the clamps keeping each thumb screw loose enough to still allow the clamps to move on the frame.

STEP FOUR – Center the windshield at the desired height. Tighten the bolts on the clamps and the thumb screws on the windshield until the rubber washer starts to compress. Caution: Over tightening thumb screws could cause the polycarbonate to crack.



PRO TIPS

When installing bolts use a small amount of **blue** thread locker, such as Loctite. This will keep the bolts from backing out during use. Tinted polycarbonate can scratch easily. It is recommended to wait until you finish your ride to clean the vent covers. Use mild cleaners such as windex with a new, unused, micro fiber cloth. Paper towels will scratch the polycarbonate. Do not apply pressure during the cleaning process or you may scuff the polycarbonate