



UTV
ZILLA™

Instructions Roof RZR 170

Read through all instructions before install.

6 – Rubber Coated Clamp 1.25”

6 – Bolt ¼-20 × 1”

6 – Locknut 1/4”

12 – Flat Washer 1/4”



Clamp Orientation

STEP ONE – Put the clamps on the roll cage in the approximate locations to line up with the holes in the roof. Use the provided washers on the top of the roof and underneath, before the nut is added to the bolt.

STEP TWO – Tighten each bolt to complete the roof installation. Over-tightening could cause the roof to dip inward.