



UTV  
**ZILLA™**

## Instructions Rear Window RZR 170

Read through all instructions before install.

- 4** – Rubber Coated Clamp 1.25"
- 4** – Bolt ¼-20 × 1"
- 4** – Locknut 1/4"
- 8** – Flat Washer 1/4"
- 1** – Bottom Bulb Seal (29")



**STEP ONE** – Put the clamps on the roll cage in the approximate locations to line up with the holes in the window.

**STEP TWO** – Place trim onto the bottom of the window where it will contact the plastics. Install the rear window from the interior of the cage.