



**UTV  
ZILLA™**

## RZR 170 Windshield Instructions

Read through all instructions before install.

**4** – Rubber Coated Clamp 1.25”

**4** – Bolt ¼-20 × 1”

**4** – Locknut 1/4”

**8** – Flat Washer 1/4”



**Passanger Side  
Clamp Orientation**

**STEP ONE** – Place the clamps onto the roll cage in the approximate locations to line up with the windshield frame holes. Place a washer on each bolt then insert, add another washer and lastly the locknut. Then hand tighten each bolt until the windshield is secure.