



Installation instructions for Polycarbonate Windshields with quick straps

IMPORTANT!! Before removing film from the windshield, verify that you have the correct part by holding up to Machine. Make sure it matches the hood contour and lines up with the roll cage correctly. We do not accept returns for windshields that have the film removed.

Step 1. Install Bottom Trim Seal.

Pull back film on each side approximately 1 inch on both sides as shown in picture to the right.



Start at the corner and push trim on very hard till bottoms out in channel. It helps to rock it back and forth slightly.

The most difficult part is the corners. Make sure you get them in tight as shown in the picture or the windshield may not fit well.



When complete the trim should cover the bottom edge as show in 3rd picture

Step 2. Install Straps as shown below.

Pull the film back away from the side edges as shown below. Insert each strap into the front of the windshield with the fuzzy side facing the middle of the windshield.



Pull each strap all the way in until the ring bottoms out against the front of the windshield. If they are not pulled in all the way it may seem like the strap is too long when trying to cinch it tight.

