



Polycarbonate Windshield Install Instructions

Step 1. Install Rubber Edge Trim on bottom edge by pulling back the protective film on both sides. Starting at the second corner firmly push edge trim on to bottom edge. This takes some effort. Rocking the trim back and forth may help it go on.

Step 2. Remove remaining protective film and place windshield in place on machine. The metal ring on the straps should be pulled tight against the front of the windshield before looping through and strapping tight. If they are not pulled tight, the strap may feel like it is too long to strap tight.

Check out more of our UTV products at [UTVZILLA.com](https://www.UTVZILLA.com)