

RZR 1000, 900 Aluminum Roof Instructions

Please read through all instructions to get familiar with install before beginning install.

Remove the two top factory screws in the visor. Also remove the clip on nuts that were used for those two bolts. Use two of the included ¼" bolts to fasten the roof (loosely) thru the two holes. Use washers on the bolt side, and on the nuts below. Tighten these two bolts so they are a little loose.

Install the rear two bolts through the roof and the factory holes in the roll cage brackets the same as the front.

Make sure the front edge of roof is lined up good with stock visor before beginning to tighten any of the fasteners. Tighten up all of the bolts starting with the first two that were installed thru the visor. Then tighten the rear two bolts.

Hardware List

(4) ¼-20 x 1.25 Screws

(4) ¼-20 Lock Nuts

(8) ¼" Flat Washers

Check out our site at UTVZILLA.com for more great products!