

XP4, 900, 1000 4 ALUMINUM Roof Installation Instructions

Please read through all instructions to get familiar with install before beginning install.

Step 1. Attach the front and rear sections of the roof together. This can be done on a table, or on the roll cage. Place roof sections on top of the rZR with the **FRONT section OVERLAPPING the REAR**. Use the 5 smaller bolts and nuts to fasten two sections together. Insert the bolts from the top thru to the bottom so the nuts are on the bottom of the roof. No washers are used for this joint. Tighten bolts so they are snug holding the two parts tightly together.

Step 2. Install Clamps and front 2 bolts (not drilled holes yet). Remove the two top factory screws in the visor. Also remove the clip on nuts that were used for those two screws. Use two of the included ¼" bolts to fasten the roof (loosely) thru the two holes. Use washers on the bolt and nut side. Tighten these bolts so they are a little loose.

Slide a clamp over the roll cage under each slotted hole on the remainder of the roof, (8 clamps). Slide a washer onto each bolt before inserting thru roof and into clamp. Use another washer on the nut side. Start every nut and bolt before tightening down any of them.

Make sure the front edge of roof is lined up with stock visor before beginning to tighten any of the fasteners. Tighten up all of the bolts starting with the first two that were installed thru the visor. Then tighten the bolts thru the clamps.

****HINT FOR TIGHTENING CLAMP BOLTS**** When tightening the bolts with the clamps they have a tendency to pull down on the roof in the middle. To help this, lift up on the clamps so that they are turned higher before tightening so when they tighten up they end up flat with the top of the cage and not pulling down in the center. You may need to tighten and loosen a couple times to get flat. This is not a necessary step as it won't hurt anything for the roof to be pulled down a little in the middle.

Hardware List

- (10) ¼-20 x 1" Screws
- (10) ¼-20 Lock Nuts
- (20) ¼" Flat Washers
- (5) 10-24 x ½" Screws
- (5) 10-24 Locknuts
- (8) 1,3/4" Clamp

Check out our websites at utvzilla.com and motoarmor.com for more products!