

# UTVZILLA

## Polycarbonate Rear Window Installation Instructions (RZR XP 1000, TURBO, 900)

### PARTS:

#### QTY

- (1) Main Window
- (1) Lower Panel
- (6) Quick Cinch Straps
- (8) 10-24 X 5/8" Screws
- (8) 10-24 Lock Nuts
- (2) Harness Hole Covers



You can attach the lower panel before OR after installing the main window. It is easier to get the window in place if you install it before bolting on the lower panel. If you have harnesses already installed then you will want to bolt on the lower panel after you install the main window so you can place it around the harnesses.

Step 1. Remove back seats. (this is not 100% necessary, but it makes installation easier.)

Step 2. Install the Main window by positioning the window INSIDE of the roll cage and strapping on with quick straps.

Pull the protective film partially off so that there is at least 2-3 inches of exposed plastic all the way around the window.

Insert each of the 6 straps through the window from the inside. Insert each strap so that the soft fuzzy side is facing AWAY from the closest edge. Pull each strap all the way through the slot until the metal loop bottoms out on the window. When strapping the window in place, loop the strap around the tube and loop it back through the chrome loop on the strap.

WHEN CINCHING THE STRAP TIGHT, HOLD THE CHROME LOOP AGAINST THE WINDOW WITH A FINGER SO THAT THE STRAP DOES NOT SLIP AND ROTATE. IF THE STRAP SLIPS IT MAY FEEL LIKE IT IS TOO LONG.

Leave the bottom two straps loose until after you install the lower panel.

Step 3. Install lower panel. Position lower panel so that it is overlapping on the inside of the main window. Use 4 screws and nuts to bolt together. Tighten each nut snug. They don't need to be extremely tight. For the best appearance, install screws so that the head is on the outside and the nut is on the inside of the RZR.

Step 4. Install harness hole covers. If not using harnesses, install the two covers by bolting them in place over the holes. Use the 4 remaining screws and nuts.

### Care and Maintenance:

Polycarbonate is very strong and durable but it can scratch and scuff up easily. Never wipe a dirty window with anything! First spray off with water to remove dust, dirt, mud, or debris of any kind. Then only use a new or newly washed microfiber towel to lightly dry. Do not push hard as it may scuff. The only cleaner we recommend would be a dusting furniture polish like pledge or similar.