

Hardware:

(qty)

- 1 47" Length of 1/8" edge trim
- 2 11" Length of 1/8" edge trim
- 2 14.5" Length of 1/4" edge trim
- 10 Bar clamps
- 10 .25" x 1" Bolts (Black SS)
- 20 1/4" Flat Washers (Black SS)
- 10 1/4" Locknuts



Step 1: Install rubber trim in designated locations. The long 47" Trim goes on the bottom edge of the metal frame. The 11" lengths go on the top corners of the metal frame. The 14.5" lengths go on the two notches on the plastic panel. (where harnesses may be attached to the cross bar)

Step 2: Install the lower plastic panel on the inside of the roll cage. Use 4 clamps as shown in the pictures below.





Step 3: Install glass windshield on outside of frame. Clip the clamps on approximate positions and lift windshield into place, (this is much easier with two people). Use remaining bolts, washers, and locknuts to secure in place as shown below.

