



Instructions Glass Windshield RZR 800, 900

Read through all instructions before install.

4 – Rubber Coated Clamp 1.75”

4 – Bolt ¼-20 × 1”

4 – Locknut 1/4”

8 – Flat Washer 1/4”



Clamp Orientation

STEP ONE – Place the clamps onto the roll cage in the approximate locations to line up with the windshield frame holes. Place a washer on each bolt then insert, add another washer and lastly the locknut. Then hand tighten each bolt until the windshield is secure.