



# Instructions PRO XP Plastic Roof 2 Seat

Read through all instructions before install.

*2" Bar Clamps – 3*

*¼" x 1.25" Bolts BSS – 3*

*¼" x 1" Bolts BSS – 8*

*¼" Flat Washers BSS – 22*

*¼" Lock Nuts – 11*

*Edge Seal ½" – 155"*

**STEP ONE** – Remove the backing to the edge seal and place along the bottom edges where the roof contacts the cage.

**STEP TWO** – Place all clamps on the roll cage in approximate locations on the sides and back. Bolt through each clamp with the 1.25" bolts and the holes in the cage with the 1" bolts.

