



Rear Window for Polaris Pro XP

Read through all instructions before install.

- 4** – Quick Straps
- 2** – Bolt $\frac{1}{4}$ -20 \times $\frac{3}{4}$ "
- 2** – Locknut $\frac{1}{4}$ "
- 4** – Flat Washer $\frac{1}{4}$ "
- 1** – Bottom Bulb Seal (50")
- 1** – Side Bulb Seal (72")
- 1** – Bottom Mounting Bracket

STEP ONE – Bolt the bottom mounting bracket to the plastic between the back seating. Remove and reuse the factory Polaris bolts that are already in place. Refer to the picture for location. The tabs should be facing forward.



STEP TWO – Remove the film from both sides of the windshield. Install the windshield in place from inside the machine. Bolt the windshield to the mounting bracket using the provided bolts, nuts, and washers. Use a washer on both sides of the bolts. Insert the straps into each hole and tighten making sure to keep the windshield centered.