



UTV
ZILLA™

Instructions PRO XP Half PC WS

Read through all instructions before install.

Straps – 2

Side bulb trim – 36"

STEP ONE – Remove the film on both sides of the windshield. Be careful not to scratch it.

STEP TWO – Insert the straps into the holes starting from the front of the windshield pulling them in until the metal ring is touching the windshield. Make sure the fuzzy part of the strap is pointed to the inside of the windshield when inserting.

STEP THREE Push the trim onto the top of the windshield. Take your time as it can be a tight fit.



Strap Orientation