



# UTV ZILLA™

## Instructions Turbo S 2 Roof

Read through all instructions before install.

- 8** – Rubber Coated Clamp 1.75"
- 8** – Bolt 1/4-20 x 1.25"
- 8** – Locknut 1/4"
- 16** – Flat Washer 1/4"
- 1** – 1/8" x 1/2 Adhesive Foam (110")
- 1** – 3/8" x 1/2 Adhesive Foam (50")



Clamp Orientation

**STEP ONE** – Install foam on the cage or on the roof. Use the thicker foam on the front part of the cage. (optional: Place the foam onto the roof instead of the roll bars. It may be more difficult to line up.)

**STEP TWO** – Put the clamps on the roll cage in the approximate locations to line up with the roof holes.

**STEP THREE** – Place the roof on the cage and bolt to the clamps using the 1.25" bolts. Tighten the bolts from the front to the back to get a tight seal on the front of the roof.

