



UTV ZILLA™

Instructions Turbo S 4 Roof

Read through all instructions before install.

12 – Rubber Coated Clamp 1.75”

3 – Bolt 1/4-20 × 3/4”

12 – Bolt 1/4-20 × 1.25”

15 – Locknut 1/4”

30 – Flat Washer 1/4”

1 – 1/8 × 1/2” Adhesive Foam (170”)



STEP ONE – Optional: Install foam on the cage or on the roof where the roof contacts the cage. Also, foam can be placed between the over lapping area of the two halves but is not nessecary.

STEP TWO – Bolt the roof together using the three included 3/4” bolts. (shown in picture)

STEP THREE – Put the clamps on the roll cage in the approximate locations to line up with the roof holes. Put the roof on and use 1.25” bolts and washers to secure the roof to the machine.

