



# UTV ZILLA™

## Instructions Turbo S Rear PC WS

Read through all instructions before install.

Straps – 6

Skirt Trim 14.5" – 4

1/2" adhesive foam – 44"

**STEP ONE** – Remove the film on both sides of the windshield. Be careful not to scratch the windshield. Place the adhesive foam on the bottom of the windshield facing the rear of the machine so it seals against the plastics.

**STEP TWO** – Insert the straps into the holes starting from the interior side of the windshield pulling them in until the metal ring is touching the windshield. Make sure the fuzzy part of the strap is pointed to the center of the windshield when inserting.

**STEP THREE** – To help make the install of the harness hole trim easier try using the handle of a screw driver to push the trim into place. The skirt trim will need to be placed on the top and bottom of each harness hole.



**STEP FOUR** – To completely wrap the velcro on the bottom straps you will need to place a sheet of paper, such as the instructions, in between the strap and push the end into place. Once the strap is in position pull the paper instructions out while holding the strap in place and it will let the velcro hook together. Repeat the process for both bottom straps. Once the top two straps are wrapped onto the cage the installation is complete.

