



## Half Windshield for Textron Wildcat Trail

Read through all instructions before install.

### Hardware:

(qty)

- 1 43" Piece of edge trim
- 4 Billet Clamps (gray)
- 4 1/4" x 2.50" Bolts (SS)
- 4 1/4" Flat Washers (SS)



**Step 1:** Install rubber edge trim along bottom edge of windshield for protection during install and use. This can be difficult. Rocking the trim back and forth while applying helps it go on easier. Cut excess trim with scissors or snips.

**Step 2:** Place the billet clamps on the frame in approximate locations. Place the windshield in position. Bolt the windshield to the clamps by putting a flat washer on each bolt before inserting through the windshield. Before tightening any bolts center the windshield on the machine at desired height.

**Step 3:** Tighten each bolt snug. Caution: Over tightening bolts could cause damage to polycarbonate.