



Aluminum and Plastic Roof for Textron Wildcat XX

Read through all instructions before
install.

Hardware:

(qty)

- 6 1.75" Bar Clamps
- 6 1/4" x 1.25" Bolts (BSS)
- 4 1/4" x 1" Bolts (BSS)
- 20 1/4" Flat Washers (BSS)
- 10 1/4" Lock Nuts
- 160" of 1/2" Foam



Step 1: Remove the backing to the foam and place along the bottom edges where the roof contacts the cage.

Step 2: Place all clamps on the roll cage in approximate locations. Bolt each clamp to the roof starting with the clamps on the back and front then move to the clamps on the sides. Put a flat washer on a 1.25" long bolt before inserting through the bolt holes in the roof. Place another washer on the underside of the clamp and a lock nut.

Step 3: Finish bolting the corners of the roof to the holes in the roll cage brackets using the 1" long bolts and following the same hardware components as in Step 2.

