



Rear Windshield for Wildcat XX

Read through all instructions before install



Hardware:

(qty)

52"	3/16" Bottom Bulb Trim
4	Billet Clamps (Gray)
4	1/4" x 2.5" Bolts (BSS)
4	1/4" Flat Washers (BSS)
2	Straps

Step 1: Install rubber edge trim along bottom edge of windshield for protection during install and use. This can be difficult. Rocking the trim back and forth while applying helps it go on easier. Cut excess trim with scissors or snips.

Step 2: Remove or slide seats forward as far as possible. Place the windshield in position by starting inside the machine and placing one side in place behind the vertical bars then follow with the other side. The sides of the windshield will be located behind the vertical frame bars and the upper bent part of the windshield will be located in front of the top horizontal frame bar.

Step 3: Place the billet clamps on the frame in approximate locations. Bolt windshield to the clamps by putting a flat washer on each bolt before inserting through the windshield holes. Tighten each bolt until snug. Caution: Over tightening bolts could cause the polycarbonate to crack.

Step 4: Insert the straps into the upper slots with the metal loop on the inside of the cab and the fuzzy sides facing down. Keep metal loop tight against windshield or strap may seem too long. Pull tight.

