



Full Windshield for Textron Wildcat XX

Read through all instructions before
install.

Hardware:

(qty)

52" 3/16" Bottom Bulb Trim

4 Straps

Step 1: Install trim along bottom edge of windshield for protection during install and use. This can be difficult. Rocking the trim back and forth while applying helps it go on easier.



Step 2: Install straps with the fuzzy sides facing toward the center of windshield and the metal loop on the front side of the windshield.

Step 3: Center windshield on the machine at desired height. Wrap straps around frame and pull tight. Keep metal loop tight against windshield or strap may seem too long.