



## Half Windshield for Textron Wildcat XX

Read through all instructions before install.

### Hardware:

(qty)

52" 3/16" Bottom Bulb Trim

2 Straps



**Step 1:** Install trim along bottom edge of windshield

for protection during install and use. This can be difficult. Rocking the trim back and forth while applying helps it go on easier.

**Step 2:** Install straps with the fuzzy sides facing toward the center of windshield and the metal loop on the front side of the windshield.

**Step 3:** Center windshield on the machine at desired height. Wrap straps around frame and pull tight. Keep metal loop tight against windshield or strap may seem too long.