



Polycarbonate REAR WINDOW Installation Instructions (Can Am X3)

Read through all instructions before assembly and install

PARTS:

QTY

- (1) Main Window
- (1) Bottom fill panel
- (5) Quick Cinch Straps
- (4) ¼ x 1" Screws
- (4) ¼" Locknuts
- (2) HDPE Plates



Initial Assembly. Use the supplied bolts and nuts to attach the plastic plates to the BACK of the window as shown in the picture above. To tell the front from the back look at the two bends near the top corners. The corners bend forward to follow the shape of the cage. Tighten hardware snug. Over tightening can cause damage to windshield.

Insert each strap into the slots with the fuzzy side facing toward the center of the windshield. Insert straps all the way till the metal ring bottoms out against the plastic.

Install on Machine. Carefully place window in place on machine. To get into place you need to bow the window so you can slide the two top corners under the cage gussets. Strap the window on by looping the straps around the cage and through the metal rings. Pull the straps tight. It helps to put a finger on the metal ring to keep it from rotating while pulling tight.

Install lower panel. To install the lower panel, set it in place from INSIDE the cab. Run the two bottom straps over the top edge then through the holes and out the back. Then loop them around the bar and through the metal rings. Make sure the panel is sitting down against the bed. This helps hold it in place when the straps are tight.



Care and Maintenance:

Polycarbonate is very strong and durable but it can scratch and scuff up easily. Never wipe a dirty window with anything! First spray off with water to remove dust, dirt, mud, or debris of any kind. Then only use a new or newly washed micro fiber towel to lightly dry. Do not push hard as it may scuff. The only cleaner we recommend would be a dusting furniture polish like pledge or similar.