



Polycarbonate Tinted Visor Installation Instructions (Can Am X3)

Read through all instructions before assembly and install

PARTS:

QTY

- (1) Polycarbonate Visor
- (2) 12" Quick Straps
- (2) 18" Quick Straps



Initial Set Up.

Insert each strap into the slots with the fuzzy side facing toward the center of the windshield. Insert the straps all the way till the metal or plastic rings bottom out against the visor. You can insert from either side of the visor. Just depends on what side you want the ring to be seen. Use the longer 18" straps on the two side slots.

Install on Machine. Carefully place the Visor in place on the machine. Strap the Visor on by looping the straps around the cage and through the rings. Pull the straps tight and strap them on. It helps to put a finger on the ring to keep it from rotating while pulling tight.

Care and Maintenance:

Polycarbonate is very strong and durable but it can scratch and scuff up easily. Never wipe a dirty window with anything! First spray off with water to remove dust, dirt, mud, or debris of any kind. Then only use a new or newly washed microfiber towel to lightly dry. Do not push hard as it may scuff. The only cleaner we recommend would be a dusting furniture polish like pledge or similar.