



## UTVZILLA

### Polycarbonate Half Windshield Installation Instructions (Can Am X3)

Read through all instructions before assembly and install

**PARTS:**

**QTY**

- (1) Main Window
- (1) Bottom Seal Trim
- (2) Quick Cinch Straps
- (4) ¼ x 1" Screws
- (4) ¼" Locknuts
- (2) Black Plastic Plates



**Initial Assembly.** Use the supplied bolts and nuts to attach the plastic plates to the **BACK** of the windshield as pictured. Tighten the hardware so it is snug. (NO NEED TO TIGHTEN VERY TIGHT)

Push the bottom trim on to the edge starting at the corner shown in the picture. Position the trim so that the round bulb seal faces down toward the dash.

Insert each strap into the slots with the fuzzy side facing toward the center of the windshield. Insert straps all the way till the metal ring bottoms out against the plastic.

**Install on Machine.** Carefully place the windshield in place on the machine. Slide the bottom edge between the plastic hood and the dashboard. You can position the windshield lower or higher depending on preference. Strap the windshield on by looping the strap around the cage and through the metal ring. Pull the strap tight. It helps to put a finger on the metal ring to keep it from rotating while pulling tight.

**Care and Maintenance:**

Polycarbonate is very strong and durable but it can scratch and scuff up easily. Never wipe a dirty window with anything! First spray off with water to remove dust, dirt, mud, or debris of any kind. Then only use a new or newly washed microfiber towel to lightly dry. Do not push hard as it may scuff. The only cleaner we recommend would be a dusting furniture polish like pledge or similar.